

Lonsdor K518ISE Hibernation Function update instruction

How to update Lonsdor K518ISE Hibernation Function?

Updated Device: Lonsdor K518

Updated Condition: for all K518 devices with working normally

Updated Content: Added Hibernation function; Kernel update supported


Updated Version: [K518 APK V1.5.25](#)



Preparation for Update:

1. Power on the device or keep the battery level over 80%.
2. Make sure wifi network is in good condition and the device receives signal normally;


Update steps:

1. Click [One key update] and skip to below interface. Then click the first button to update system. When the update complete, click [OK] to reboot the device.







2. After rebooting, click and enter [Settings] menu, you will find there are two additional function buttons: [Update Kernel] and [Display Settings].




3. Click [Update Kernel] first and skip to below interface, then press [Update] to update the kernel.







4. Click [\[Install\]](#) after updating the kernel file. And the device will reboot to install kernel.




5. Blank screen is normal during the installation. The whole process will take 5 minutes, be patient to wait and don't restart the device manually.



6. The update complete when the password input interface appears. Screen auto-lock in the [Display Settings] is added.



7. Enter [Settings]→[Display Settings] to adjust the screen brightness and screen auto-locking time .



8. The benefits for update: Save power to prolong stand-by time. Auto standby function can prevent the device from being overheated in hot summer.